


Ski & Snowboard

WAXING

Tips & Tricks



Must Have

- Waxing iron
- Wax
- Plexi scraper
- Brush

Nice To Have:

- Ski vise
- Scraper sharpener

IRON: Clothes irons can get too hot and burn the wax. In extreme cases you could melt or weaken the epoxy holding the ski or snowboard together. Get and use a waxing iron.

BRUSH: Nylon is good but bronze is better, faster. Oval brushes speed up the process if doing multiple applications.

SCRAPER: Have several and keep them sharp.

WISE: Keeps things stationary while you scrape and brush. Ones that tip on an angle help when sharpening edges.

Waxing

1. Be sure the base is clean and dry. Use a Scotch Brite pad lightly to freshen the base if dirty. Wipe with a clean, lint free cloth.
2. Set the iron temperature to match the wax being used. Drip wax, sparsely, all along the base. Go easy—whatever you put on you will be taking off.
3. Melt and spread the wax evenly over the entire base, then set aside to completely cool.
4. With edge of scraper, remove drips along edges, then scrape the base, working tip-to-tail, until no more wax comes up.
5. Brush, working tip-to-tail, at least a half-dozen strokes, but you can't brush too much.
6. Wipe down with clean, lint-free cloth. Go have fun on the slopes.




Did you know?

If you scrape or brush tail-to-tip you will raise hairs of plastic on the base which will reduce glide and slow you down. **ALWAYS WORK TIP – to – TAIL** when scraping or brushing. **ALWAYS.**

Ski and snowboard bases are porous. Waxing them with an iron pushes wax INTO the base, making the wax last longer so you go faster. The more you wax the better things get.



Avie's staff are dedicated to making your time on the slopes the very best it can be. Maintaining your gear in top performing condition is a key element for fun on the slopes.



Be at your best!

—we can help—